

Installation instructions for drawer safes

1 Remove the drawer

1.1 Open the door and pull the drawer out to the stop.

1.2 Pull up the black plastic buckle on the left side and pull down the buckle on the right side as shown in the picture below.

1.3 Remove the drawer from the safe body.



2. Fix the safe body

Place the safe body in the cabinet and adjust it to a suitable position, fixing the safe body with the four screws at the bottom as shown in the figure below.



3. Put the drawer back in place

3.1 Ensure that the ball part is in the outermost position as shown in the figure below.

3.2 Push the drawer back by connecting the slides, there is no need to press the black plastic buckle when pushing the drawer back.

